


PST Pre Setting Tools

Dimensions in mm



Part No.	D1 	M	L	S1
PST06L	06	M12 x 1.5	45	24
PST08L	08	M14 x 1.5	45	24
PST10L	10	M16 x 1.5	45	24
PST12L	12	M18 x 1.5	45	24
PST15L	15	M22 x 1.5	45	24
PST18L	18	M26 x 1.5	45	24
PST22L	22	M30 x 2.0	60	50
PST28L	28	M36 x 2.0	60	50
PST35L	35	M45 x 2.0	60	50
PST42L	42	M52 x 2.0	60	50
PST06S	06	M14 x 1.5	45	24
PST08S	08	M16 x 1.5	45	24
PST10S	10	M18 x 1.5	45	24
PST12S	12	M20 x 1.5	45	24
PST16S	16	M24 x 1.5	45	24
PST20S	20	M30 x 2.0	60	50
PST25S	25	M36 x 2.0	60	50
PST30S	30	M42 x 2.0	60	50
PST38S	38	M52 x 2.0	60	50